- •True double-conversion
- •Microprocessor control optimizes reliability
- •Input power factor correction
- •Output power factor 0.9
- •Wide input voltage
- •Converter mode available
- •ECO mode for energy saving
- •Adjustable battery numbers
- •Generator compatible
- •Smart SNMP works well with either USB or RS-232 together
- •Comprehensive display allows easy monitoring and access of UPS status





WINNER VALUE + ONLINE UPS SELECTION GUIDE

MODEL		Winner Value + 1K	Winner Value + 2K	Winner Value + 3K	
PHASE			Single phase with ground	•	
CAPACITY		1000 VA / 900 W	2000 VA / 1800 W	3000 VA / 2700 W	
INPUT		1000 1717 000 11	2000 1717 1000 11	0000 V/(/ 2/00 V/	
Nominal V	oltage	110/115/	120/127VAC or 200/208/220/23	0/240VAC	
Tremma venage					
Voltage Range		60-145 VAC or 120-300 VAC (Based on load at 50%)			
		90-145 VAC or 180-280 VAC (Based on load at 100%)			
Frequency Range		40Hz ~ 70 Hz			
Power Factor		≥ 0.99 @ Nominal Voltage (100% load)			
OUTPU					
Output Voltage		110/115/120/127VAC or 200/208/220/230/240VAC			
Voltage Regulation		± 1%			
Frequency Range (Synchronized Range)		47~ 53 Hz or 57 ~ 63 Hz			
Frequency Range (Batt. Mode)		50 Hz or 60Hz ± 0.5%			
Current Crest Ratio		3:1			
Harmonic Distortion		≦ 3 % THD (Linear Load)			
		≦ 6 % THD (Non-linear Load)			
Transfer	AC Mode to Battery Mode	Zero			
Time	Inverter to Bypass	4 ms (Typical)			
Waveform (Batt. Mode)		Pure Sinewave			
EFFICIE	NCY				
To AC Mode		88%	89%	90%	
To Battery Mode		83%	85%	88%	
BATTER		-		1	
Standard Model	Battery Type	12 V / 9 AH	12 V / 9 AH	12 V / 9 AH	
	Numbers	2	4	6	
	Typical Recharge Time		4 hours recover to 90% capacity	I.	
	Charging Current (max.)	1.0 A			
	Charging Voltage	27.4VDC ± 1%	54.7 Vpc ±1%	82.1 Vpc ±1%	
Long-run Model	Battery Type				
	Numbers	N/A			
	Charging Current (max.)				
	Charging Voltage				
INDICAT		1			
LCD		Load level Battery level A	.C mode, Battery mode, Bypass	mode, and Fault indicators	
ALARM		Zoda lovol, Battory lovol, 7	The mode, Battery mode, Bypass	mode, and radii maleators	
Battery Mode		Sounding every 4 seconds			
		Sounding every 4 seconds Sounding every second			
Low Battery Overload			Sounding twice every second		
Fault			Continuesly sounding		
PHYSICAL		Continuously sounding			
		202 v 445 202	207 v 445 · · 200	404 v 400 · 040	
Standard Model	Dimension, D x W x H (mm)	282 x 145 x 220	397 x 145 x 220	421 x 190 x 318	
	Net Weight (kgs)	9,8	17	27,6	
Long-run	Dimension, D x W x H (mm)	N/A			
Model	Net Weight (kgs)				
ENVIRO	NIVIEN I		0.0/ DIT @ 0.40% /	oin a)	
Humidity		20-90 % RH @ 0- 40℃ (non-condensing)			
Noise Level		Less than 50dBA @ 1 Meter			
MANAG					
Smart RS-232/USB		Supports Windows 2000/2003/XP/Vista/2008/7/8, Linux, Unix, and MAC			
Optional S			ement from SNMP manager and when the output voltage is as		

^{*1-3}KVA: Derate to 80% of capacity in Frequency converter mode and to 80% when the output voltage is adjusted to 100/200/208VAC 6-10KVA: Derate to 60% of capacity in Frequency converter mode and to 90% when the output voltage is adjusted to 208VAC Product specifications are subject to change without further notice